

N. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State ☒	Fee ☐
5. State Oil & Gas Lease No.	

B-155

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
(1) MAP APPLICATION FOR PERMIT - "C" FORM C-101 FOR SUCH PROPOSALS.)

WELL ☒ GAS WELL ☐ OTHER ☐

Name of Operator

TEXACO Inc.

Address of Operator

P. O. Box 728, Hobbs, New Mexico 88240

Location of Well

UNIT LETTER **P** **860** FEET FROM THE **South** LINE AND **660** FEET FROM

THE **East** LINE, SECTION **36** TOWNSHIP **17-S** RANGE **34-E** N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)

3994' (DF)

1. County

Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

OTHER **Abandon Abo, addl. Glorieta perfs.** ☒

16. Description of Notice or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Pull 2 1/16" tubing & gas lift equipment from Abo & Glorieta strings.
2. Set CIBP in Abo String @ 9100' & spot 30' cement on plug. Abandon Abo.
3. Perforate 2 7/8" Glorieta string w/2-JSPF @ 6139', 41', 45', 51', 54', 56', & 6158'.
4. Set RBP in Glorieta @ 6175' & pkr. @ 6120'. Acidize perforations 6139' - 6158' w/2000 gal. 15% NE acid in 2-equal stages using 200# rock salt & 200 Benzoic Acid Flakes between stages. Flush with treated fresh water.
5. Reset RBP @ 6120' & pkr. @ 5900'. Acidize Glorieta perfs. 5942'-6102' w/4000 gal. 15% NE acid in 4-equal stages using 200# rock salt & 200 Benzoic Acid Flakes between each stage. Flush with treated fresh water.
6. Perforate abandoned 2 7/8" Abo casing w/2-JSPF in Glorieta from 6152'-6158'.
7. Install pumping equipment. Test & place on production using one string as a vent string.

17. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED

[Signature]

TITLE **Asst. Dist. Supt.**

DATE **1-15-79**

Orig. Sign. *[Signature]*
Jerry Seznec

APPROVED BY

[Signature]

TITLE

DATE

JAN 19 1979

CONDITIONS OF APPROVAL, IF ANY: