

CASING PROGRAM

We propose to use the following strings of Casing and to cement them as indicated:

Size of Hole	Size of Casing	Weight per Foot	New or Second Hand	Depth	Sacks Cement
15"	11-3/4"	42# H-40	New	1530'	*1100
10-5/8"	8-5/8"	24# & 32# J-55 & H-40	New	3200'	** 750
7-5/8"	2-7/8"	6.5# J-55Acme	New	6850'	***
"	"	" " "	"	"	***

- *900 sacks class "C" 4% gel followed by 200 sacks class "C" neat.
- **600 sacks class "C" 4% gel followed by 150 sacks class "C" neat.
- ***Install scratchers and centralizers, remove lacquer and apply "Casing-Kote" on both strings opposite all pays. Preceed slurry with 500 gal. mud scrub followed by 30 bbls. salt water. Cement with 300 sacks class "C" 8% gel followed by 300 sacks class "C" 4% gel.

FORMATION TOPS EXPECTED

Anhydrite	1515'
Top of Salt	1620'
Base of Salt	2695'
Yates	2795'
San Andres	4330'
Glorieta	5875'
Blaine (mkr)	6535'
Total Depth	6850'