

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1030-1	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - I" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator TEXACO Inc.		8. Farm or Lease Name N.M. 'T' St.NCT-1
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240		9. Well No. 2
4. Location of Well UNIT LETTER <u>H</u> , <u>1965</u> FEET FROM THE <u>North</u> LINE AND <u>865</u> FEET FROM THE <u>East</u> LINE, SECTION <u>25</u> TOWNSHIP <u>17-S</u> RANGE <u>34-E</u> N.M.P.M.		10. Field and Pool, or Wildcat Vacuum Glorieta
15. Elevation (Show whether DF, RT, GR, etc.) 3992' (GR)		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Repair Water Flow

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged up. Pull rods & pump. Install BOP. Pull tubing.
2. Set RBP @ 4032'. Spot 20' Sand on plug.
3. Perforate 2 7/8" Csg W/2-JS @ 1648'.
4. Cement 2 7/8" Csg perfs. @ 1648' W/500 Sx. Class 'H' Cement containing 2% CaCl. Squeeze W/Add'l 150 Sx. Class 'H' Cement containing 2% CaCl. WOC. DOC. Test cement. Did not hold.
5. Pump 250 Gals. 15% Acid down 2 7/8" Csg. Cement Csg perfs @ 1648' W/75 Sx. Class 'H' Cement containing 2% CaCl. WOC. DOC. Tested Csg to 600#. Tested OK.
6. Install pumping equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Jerry Dutton</u>	TITLE <u>Asst. Dist. Mgr.</u>	DATE <u>7-30-81</u>
APPROVED BY <u>Dan L. Soper</u>	TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		