

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>	
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name Texaco Hammon "A"	
9. Well No. 2	
10. Field and Pool, or Wildcat Pearl Queen	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator Tex-Star Oil & Gas Corporation
3. Address of Operator 1000 Oil & Gas Bldg., Wichita Falls, Texas
4. Location of Well UNIT LETTER C , 1650 FEET FROM THE West LINE AND 990 FEET FROM THE North LINE, SECTION 24 TOWNSHIP 19S RANGE 35E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3716.5 GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1/1/65 Drld. to TD - 5100' Pull Out hole for Log

1/2/65 Ran 158 jts (5108.33') 4 1/2" OD 10.50# J-55 8 R ST & C
New Casing & set @ 5098', cemented w/100 sacks Incore cement
plus 18# salt per sack, plug 2% gel added, and 100 sacks (50-50)
Boz mix 2o2 mix plus 4% gel. Plug down 5:15 AM WOC

1/6/65 WOC til 10:00 AM Hook up Western Company and test casing to 3500#
for 30 minutes. Casing test OK. Prepare to perforate.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED M. J. McLaughlin

TITLE **District Superintendent**

DATE **1/14/65**

APPROVED BY [Signature]

TITLE _____

DATE _____

CONDITIONS OF APPROVAL, IF ANY: