

FEB 24 1970

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

5a. Indicate Type of Lease
State Fee

5. State Oil & Gas Lease No.
OG-5121

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator TEXACO Inc.	8. Farm or Lease Name New Mexico 'DG' State
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER J 2310 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 18 TOWNSHIP 17-3 RANGE 37-E NMPM.	10. Field and Pool, or Wildcat Midway San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 3804' (DF)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER _____ <input type="checkbox"/>	OTHER Shut Off Water <input checked="" type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following work has been completed on subject well:

1. Pull rods and tubing.
2. Ran tubing w/packer and set at 4905'.
3. Pump 24 bbls treated lease crude followed w/115 sx Class C Incor in 1000 gals visqueeze.
4. Let visqueeze set for 24 hrs.
5. Pull tubing w/packer.
6. Run tubing, rods, test and return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE **Assistant District Superintendent** DATE **February 23, 1970**

APPROVED BY  TITLE _____ DATE **FEB 25 1970**

CONDITIONS OF APPROVAL, IF ANY: