

WELL WORK RECOMMENDATIONS
Proposals for Well Reconditioning and Subsurface Maintenance
Workovers, Expense DD's, PB's, and Conversions

Lease: Bridges Santa Fe State Com. Well No. 1
Field: North Vacuum (Abo)
County: Lea State: New Mexico

RECOMMENDED PROCEDURE:

1. Move in a pulling unit and pull the producing equipment.
2. Set a CIBP at approximately 10,000'. Spot a 20' (4 sx) cement plug on top of the CIBP.
3. Return the well to production as a single Abo producer.

JESmith/mw
11/14/72