

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.
NM-25457

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
Jewett Federal #1

9. API Well No.
30-025-23661

10. Field and Pool, or Exploratory Area
Querecho Plains Bone Spring

11. County or Parish, State
Lea Co., NM

SUBMIT IN TRIPLICATE

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
Manzano Oil Corporation

3. Address and Telephone No.
P.O. Box 2107, Roswell, NM 88202-2107

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
660' FSL & 660' FEL
Section 15, T18S-R32E

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION	
<input type="checkbox"/> Notice of Intent	<input type="checkbox"/> Abandonment	<input checked="" type="checkbox"/> Change of Plans
<input checked="" type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other	<input type="checkbox"/> Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to run 5-1/2" 17# csg to 8550'± w/DV tool @ 3100'
Cement 1st stage from 5-1/2" shoe back to 5500'.
Cement 2nd stage from DV tool @ 3100' back to 100' above the 13-3/8" csg shoe or 510'
NOTE: Actual 8-5/8" stub found @ 3050' (2-2-92) - reported was 8-5/8" stub @ 1370'

RECEIVED FOR REVIEW
APR 1 1992
BUREAU OF LAND MANAGEMENT
NEW MEXICO

14. I hereby certify that the foregoing is true and correct

Signed Jana J. King

Title Production Analyst

Date 2/3/92

(This space for Federal or State office use)

Approved by _____

Conditions of approval, if any: _____

Title _____

Date _____