## STATE OF NEW MEXICO NERGY AND MINERALS DEPARTMENT

	Form C-103
DISTRIBUTION P. O. BOX 2088	Revised 10-1-78
SANTA FE, NEW MEXICO 87501	
FILE	Sa. Indicate Type of Lease
U.S.O.S.	State K Fee
LAND OFFICE	5. State Oil 6 Gas Lease No.
API No. 30-025-26402	B-2863-1
SUNDRY NOTICES AND REPORTS ON WELLS	
(OO NOT USE THIS FORM FOR PROPOSALS TO WRITE OF FORM C-101) FOR SUCH PROPOSALS.)	7. Unit Agreement Name
	East Vacuum Gb/SA Unit
well well other Injection	8. Farm or Lease Name
Name of Operator	
Phillips Petroleum Company	East Vacuum Gb/SA Unit
Address of Operator	9. Well No. Tract 3374
4001 Penbrook Street, Odessa, Texas 79762	<b>X</b> 002
Location of Well	10. Field and Pool, or Wildcat
1002	Vacuum Gb/SA
UNIT LETTER L 2681 FEET FROM THE NOTTH LINE AND 1092 FEET FROM	
17.0 35-F	
THE West LINE, SECTION 33 TOWNSHIP 17-S RANGE 35-E HMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
	Lea
3949 GR	
Check Appropriate Box To Indicate Nature of Notice, Report or Ot	her Data
NOTICE OF INTENTION TO: SUBSEQUEN'	FREPORT OF:
PLUE AND ABANDON REMEDIAL WORK	ALTERING CASING
COMMENCE DRILLING OPHS.	PLUS AND ABANDONMENT
CHANGE PLANS CASING TEST AND CEMENT JOB	
OTHER	
Set CIBP above lower perfs XX	
. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including	s estimated date of starting any proposed
work) SEE RULE 1 103.	
	into the upper
Recommended procedure to set CIBP above lower perforations to force CO	into the upper
Recommended procedure to set CIBP above lower perforations to force CO. zones:	into the upper
zones:	into the upper
zones: MI & RU DDU. Install BOP. Pull downhole equipment.	into the upper
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
MI & RU DDU. Install BOP. Pull downhole equipment.  MI & RU wireline unit to set CIBP.  Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.  Rerun injection equipment as before and return well to injection.	
zones: MI & RU DDU. Install BOP. Pull downhole equipment. MI & RU wireline unit to set CIBP. Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.	
MI & RU DDU. Install BOP. Pull downhole equipment.  MI & RU wireline unit to set CIBP.  Wireline set CIBP at 4570'. Casing collars are at 4429', 4467't, 4509 and 4674'.  Rerun injection equipment as before and return well to injection.  B. Increby certify that the information above is true and complete to the best of my knowledge and belief.	', 4451', 4592', 4633'
MI & RU DDU. Install BOP. Pull downhole equipment.  MI & RU wireline unit to set CIBP.  Wireline set CIBP at 4570'. Casing collars are at 4429', 4467'±, 4509 and 4674'.  Rerun injection equipment as before and return well to injection.	', 4451', 4592', 4633'
MI & RU DDU. Install BOP. Pull downhole equipment.  MI & RU wireline unit to set CIBP.  Wireline set CIBP at 4570'. Casing collars are at 4429', 4467't, 4509 and 4674'.  Rerun injection equipment as before and return well to injection.  B. Increby certify that the information above is true and complete to the best of my knowledge and belief.	serv.save 9-22-86
MI & RU DDU. Install BOP. Pull downhole equipment.  MI & RU wireline unit to set CIBP.  Wireline set CIBP at 4570'. Casing collars are at 4429', 4467't, 4509 and 4674'.  Rerun injection equipment as before and return well to injection.  B. Increby certify that the information above is true and complete to the best of my knowledge and belief.	', 4451', 4592', 4633'

DISTRICT I SUPERVISOR