

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well ☐ gas well ☐ other ☒ Complete as Salt Water Disposal

2. NAME OF OPERATOR
Union Oil Company of California

3. ADDRESS OF OPERATOR
P. O. Box 671 Midland, Texas

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1980' FSL and 660' FWL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒ PLUG BACK
(other) Complete as Salt Water Disposal

SUBSEQUENT REPORT

☐
☐
☐
☐
☐
☐
☐
☐
☒

RECEIVED
OCT 20 1981

OIL & GAS
U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

5. LEASE

NM-6870

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Pipeline Deep Unit Federal

9. WELL NO.

5

10. FIELD OR WILDCAT NAME Undesignated
(N. Quail Ridge Morrow Gas)

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 7, T-19-S, R-34-E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3743' G.L.

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 6- 1-81 MI RU DD Unit. Set plug in X-nipple @ 12,492'. Test plug to 2000 psi. Remove wellhead, release tubing from Otis WB pkr. Cir w/fresh water, pump 7 sx cement on top of Otis WB pkr @ 12,900'
- 6- 2-81 Pull 398 jts. 12,883' 2-7/8" OD N-80 tubing.
- 6- 5-81 Ran free point and shot 5-1/2" OD casing at 6,894'.
- 6- 6-81 Pull 167 jts. 5-1/2" OD casing.
- 6- 8-81 Ran in 2-7/8" OD tubing to 6,970'. Spotted 45 sx cement. Pull 30 stands 2-7/8" OD tubing.
- 6- 9-81 Tag cement @ 6,825', pull & lay down 55 jts. 2-7/8" OD tubing. Spotted 55 sx cement @ 5,375'.
- 6-10-81 Tag cement @ 5,315'. Pressure test plug to 1000 psi. Spotted 55 sx cement @ 5,315'. Pull 30 stands 2-7/8" OD tubing. Pumped 9.5# mud between all cement plugs.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. hereby certify that the foregoing is true and correct

SIGNED ROBERTA L. H. Parque TITLE Dist. Prod. Supt. DATE Oct 8, 1981

OCT 21 1981

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

U.S. GEOLOGICAL SURVEY
ROSWELL, NEW MEXICO

(see next page)

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

001 29 1981

☆ GPO 1979-680-655/684

U.S. DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT