Form 9-331 Dec. 1973 P. O. BOX 1900		rm Approved. dget Bureau No. 42–R1424
UNITED STATES D. MEDI AND STATES		ager Buleas (0. 42-11424
DEPARTMENT OF THE INTERIOR	NM-27572	
GEOLOGICAL SURVEY	6. IF INDIAN, ALLOTT	EE OR TRIBE NAME
SUNDRY NOTICES AND REPORTS ON WELLS	7. UNIT AGREEMENT	NAME
(Do not use this form for proposals to drill or to deepen or plug back to a different . reservoir. Use Form 9–331–C for such proposals.)	8. FARM OR LEASE NAME	
1. cil gas well gas to ther	Laguna Deep Unit Federal 9. WELL NO.	
2. NAME OF OPERATOR	3. WELL NO.	
Union Oil Company of California	10. FIELD OR WILDCAT NAME	
3. ADDRESS OF OPERATOR	East Gem-Morrow Gas Pool	
P.O. Box 671 Midland, Texas 79702	11. SEC., T., R., M., OR BLK. AND SURVEY OF	
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	AREA Sec 35 T-19-S	R-33-E
below.) AT SURFACE: 990' FSL & 1980' FWL	12. COUNTY OR PARIS	······
AT TOP PROD. INTERVAL:	Lea	New Mexico
AT TOTAL DEPTH:	14. API NO.	
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA		
	3589' GR	DW DF, KDB, AND WD)
TEST WATER SHUT-OFF	(NOTE: Report results of change on Form	multiple completion or zone 9–330.)
<ul> <li>17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state including estimated date of starting any proposed work. If well is di measured and true vertical depths for all markers and zones pertinen</li> <li>MIRU wireline unit</li> </ul>	rectionally drilled, give s	nd give pertinent dates subsurface locations and
- Set plug in "R" nipple @ 13,443'		
- RD wireline unit		
- RU DD PU NU BOP - Load tbg w/6% KCL water		
- Pressure test plug in "R" nipple to 2000 psi		
		· · · · ·
- Latch out of Otis "WB" per pkr @ 13,422'		
- Latch out of Otis "WB" per pkr @ 13,422' - If necessary, spot 10 sx cmt on top of pkr @	13,422'(if plug	ald not nold
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> </ul>		
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> <li>Spot 250 gals 10% acetic acid from ETD to 13,</li> </ul>	000'. POOH w/2.	-3/8" tbg
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> <li>Spot 250 gals 10% acetic acid from ETD to 13,</li> <li>On wireline, run permpkr w/millout extension, Set own 3 12,950'.</li> </ul>	000'. POOH w/2.	-3/8" tbg
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> <li>Spot 250 gals 10% acetic acid from ETD to 13,</li> <li>On wireline, run per pkr w/millout extension, Set pkn @ 12,950'. (Cont'd )</li> </ul>	000'. POOH w/2- 10' tbg sub and	-3/8" tbg i "R" nipple.
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> <li>Spot 250 gals 10% acetic acid from ETD to 13,</li> <li>On wireline, run permpkr w/millout extension, Set pkn @ 12,950'.</li> </ul>	000'. POOH w/2- 10' tbg sub and	-3/8" tbg i "R" nipple.
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> <li>Spot 250 gals 10% acetic acid from ETD to 13,</li> <li>On wireline, run per pkr w/millout extension, Set pkn @ 12,950'.</li> <li>Subserface Safety Valve: Manu. and Type (Cont'd.)</li> <li>18. I hereby gergify that the foregoing is true and correct</li> </ul>	000'. POOH w/2 10' tbg sub and	-3/8" tbg i "R" nipple. Set @ Ft
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> <li>Spot 250 gals 10% acetic acid from ETD to 13,</li> <li>On wireline, run permpkr w/millout extension, Set pkn @ 12,950'.</li> <li>Subsurface Safety Valve: Manu. and Type (Cont'd.)</li> <li>Is. I hereby certify that the foregoing is true and correct</li> <li>SIGNED (This space for Féderal or State off)</li> </ul>	000'. POOH w/2. 10' tbg sub and 	-3/8" tbg i "R" nipple. Set @ Ft #
<ul> <li>Latch out of Otis "WB" per pkr @ 13,422'</li> <li>If necessary, spot 10 sx cmt on top of pkr @ pressure).</li> <li>Spot 250 gals 10% acetic acid from ETD to 13,</li> <li>On wireline, run permpkr w/millout extension, Set pkn @ 12,950'.</li> <li>Subserface Safety Valve: Manu. and Type (Cont'd.)</li> <li>18. I hereby certify that the foregoing is true and correct</li> </ul>	000'. POOH w/2. 10' tbg sub and 	-3/8" tbg i "R" nipple. Set @ Ft #

•••••• \_\_\_\_\_ -----..... ····· .....

..... ..... 

-----..... -----

..... ..... 

\*See Instructions on Reverse Side 

**,** 2