## Submit 3 Copies to Appropriate District Office

## State of New Mexico Energy Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

L	API NO	).			
Λ	025	27503			

DISTRICT 1 P.O. Box 1980, Hobbs, NM 88240  OIL CONSERVATION DIVISION P.O. Box 2088	WELL API NO. 30 025 27593						
DISTRICT II Santa Fe, New Mexico 87504-2088 P.O. Drawer DD, Artesia, NM 88210	5. Indicate Type of Lease STATE X FEE						
DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410	6. State Oil & Gas Lease No.						
SUNDRY NOTICES AND REPORTS ON WELLS  ( DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	7. Lease Name or Unit Agreement Name						
1. Type of Well: OIL GAS WELL X WELL OTHER	Consolidated "A" State						
2. Name of Operator	8. Well No.						
Barbara Fasken	9. Pool name or Wildcat						
3. Address of Operator 303 W. Wall, Suite 1900, Midland, TX 79701	Midway (Devonian)						
4 Wall Location	90 Feet From The South Line						
Unit Letter 0: 1650 Feet From The East Line and 9	Feet From the Line						
Section 8 Township 17 Range 37	NMPM Lea County						
Section S Township 10. Elevation (Show whether DF, RKB, RT, GR, etc.)							
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  NOTICE OF INTENTION TO:  SUBSEQUENT REPORT OF:							
PERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDIAL WORK	ALTERING CASING						
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT							
PULL OR ALTER CASING CASING TEST AND CEMENT JOB							
OTHER: OTHER:							
12 Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, in work) SEE RULE 1103.  1. Set CIBP @ 11,700' w/35 feet cmt. on top using wireline 2. Displace well with 9.5 ppg salt mud.  3. Spot 25 sx Class "H" cement @ 8800' (Abo plug).  4. Spot 25 sx Class "C" cement @ 6300' (Glorietta plug).  5. Spot 25 sx Class "C" cement @ 4500' (8-5/8" shoe plug).  6. Cut 5-1/2" casing @ ±4000' and POW.  7. Spot 25 sx Class "C" cement 50' into casing stub. Tag  8. Spot 40 sx Class "C" cement @ 2000' (salt plug).  9. Spot 10 sx Class "C" cement @ surface.  10. Cut off 13-3/8" and 8-5/8" casing 3 feet below ground dry hole marker.  11. Remove mast anchors and level location.	dump bailer. this plug.						
I hereby certify that the information above is true and complete to the best of my knowledge and belief.  Call W. Brown TITLE Petroleum	Engineer						
SKONATURE Call W. Brown TITLE PETROTEUIII	TELEPHONE NO. 915-687-177						
TYPE OR PRINT NAME Carl W. Brown	TELEPHONE NO. 713-007-17						
(This space for State Use) ORIGINAL SIGNE	D BY JERRY SEXTON MAD (1.4. 1994						

CONDITIONS OF APPROVAL, IF ANY:

DISTRICT | SUPERVISOR \_ mle —

\_\_\_ DATE \_\_\_\_\_MAR\_ U 4 1994

THE ROSE OF THE SUMP OF MODERN 24

ACT OF VERY CONTRACT CONTRACT