

7. Acidize perfs 4436-4446 with 2000 gallons 15% NEFE as before . Wipe off BS and reset packer @ 4350'. Frac as before. SICN
8. Retrieve RBP and POOH. LD work string.
9. Rerun completion assembly and TCTPS.

NOTE: Attempt to frac both zones on the same day.