

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Encl. Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. <i>30-025-28017</i>
5. Indicate Type of Lease STATE ☒ FEE ☐
6. State Oil & Gas Lease No. <i>A-4096</i>

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Lease Name or Unit Agreement Name <i>New Mexico "DD" state</i>
2. Name of Operator <i>J & G Enterprise Ltd. Co.</i>	8. Well No. <i>5</i>
3. Address of Operator <i>P.O. Box 100, Artesia, NM 88210</i>	9. Pool name or Wildcat <i>Scharb-Wolfcamp</i>
4. Well Location Unit Letter <i>D</i> : <i>660</i> Feet From The <i>North</i> Line and <i>660</i> Feet From The <i>West</i> Line Section <i>4</i> Township <i>19S</i> Range <i>35E</i> NMPM <i>Lea</i> County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) <i>3917 GR</i>

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1 3/8" set @ 426' cemented - 350 SX - Cinc.
9 5/8" set @ 4000' " - 1470 SX - Cinc. 275 SX.
5 1/2" set @ 10802' " - 1100 SX - TOC 3966 TS
DV Tool @ 8008'
#1 - Set CIBP @ 9272 w/ 30' cement on top.
#2 - Set 100' Plug @ DV Tool 8008'
#3 - Set 100' Plug @ 5000'
#4 - Cut & lay down 5 1/2" casing @ 3900'
#5 - Set 100' stub Plug & shoe it @ 4000' - Tag Plug
#6 - Set 10 SX Surface Plug - Set Dry hole Marker (100' PLUG 450-3SD
#7 - Rig Down - Cut Anchors - Cover Pits - Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *J T Jackson* TITLE *President* DATE *4-2-97*
TYPE OR PRINT NAME *J T Jackson* TELEPHONE NO. *746-9680*

(This space for State Use) ORIGINAL SIGNED BY DISTRICT OFFICIAL

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

see above

APR 04 1997