

Cooper

The well is presently producing out of the Knowles (Devonian). There are 39 holes from 12,451' - 12,341'. The present production is uneconomic. We intend to recomplete a Wildcat Strawn.

Install a BOP & run in the hole w/a CIBP and set @ 12,250'. Cap w/35' cement. Shoot two squeeze holes @ 11,200' & two squeeze holes @ 10,485'. Run in the hole w/a cement retainer and set @ 11,100'. Cement w/350 sx H w/1% CFR-2 through bottom squeeze holes. Run in hole w/bit & drill out cement circulated out of the top squeeze holes. Test to 500 psi. Leave retainer w/100' of cement below it in place. Run in the hole with 3 1/8" gun & perforate 10,874' - 10,884' w/2 SPF. Acidize w/2500 gals 15% NEFE.