

7. GIH and set packer @ 4400'. Acidize perfs 4494-4524 with 2000 gallons 15% NEFE as before . Wipe off BS and reset packer @ 4350'. Frac as before. SION
8. Retrieve RBP and POOH. LD work string.
9. Rerun completion assembly and TOTPS.

NOTE: Attempt to frac both zones on the same day.