

Revised 10-1-78

OIL CONSERVATION DIVISION
P.O. BOX 2088
SANTA FE, NEW MEXICO 87501

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
LG-740	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator Mesa Operating Limited Partnership	8. Farm or Lease Name VACUUM STATE
3. Address of Operator P.O. Box 2009, Amarillo, Texas 79189	9. Well No. #3
4. Location of Well UNIT LETTER C 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 10 TOWNSHIP 19S RANGE 35E NMPM.	10. Field and Pool, or Wildcat Scharb Bone Springs
15. Elevation (Show whether DF, RT, GR, etc.) 3844' GR	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to P&A well as follows:

1. Set a CIBP @ $\pm 8900'$ w/35' cement on top to isolate the Bone Springs perfs (8978'-8999'); cut & pull 5 1/2" casing @ $\pm 7000'$ (TOC @ 7115');
2. Displace hole with 9.0 ppg mud-laden fluid;
3. Set a 35 sx cement plug from 50' inside 5 1/2" casing stub to 50' above; tag plug;
4. Set a 40 sx cement plug 5200'-5300' (Top of San Andres @ 5264');
5. Set a 40 sx cement plug @ 3988'-4088' (50' above and below 8 5/8" shoe);
6. Set a 30 sx cement plug from 450'-550' (50' above and below 13 3/8" casing shoe);
7. set a 10 sx cement surface plug from 35'-surface;
8. Cut off wellheads and casing stubs, install dry hole marker to P&A.

xc: NMOCD-H (0+5), Prod Rcds, CR, Reg, Land, Expl., Acctg

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Carelyn Cummings TITLE Regulatory Clerk DATE 12/31/86

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE JAN 12 1987

CONDITIONS OF APPROVAL, IF ANY: