C 4

State of New Mexico y, Minerals and Natural Resources Departmen

Form C-103 Revised 1-1-89

DISTRICT III	DISTRICT II P.O. Box 1980, Hobbs, NM 88240 DISTRICT II P.O. Drawer DD, Artesia, NM 88210 DISTRICT III DISTRICT III OIL CONSERVA'TION P.O. Box 2088 Santa Fe, New Mexico 875			88	WELL API NO. 30-025-30123	
1000 Rio Brazos F				0/304-2088	5. Indicate Type of Lease	
	Rd., Aziec, NM 87410			STATE X FEE		
					6. State Oil & Gas Lease No. NM-752	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: OIL WELL OIL WELL OTHER 2. Name of Operator					7. Lease Name or Unit Agreement Name	
					Autry C. Stephens	
3. Address of Operator 110 N. Marienfeld, Suite 110, Midland, Texas 79701					9. Pool name or Wildcat	
4. Well Location					Double "A" - Abo South	
Unit Lette		Feet From The	North	Line and165	Feet From The East Line	
Section	30 777777777777777777777777777777777777	Township 17	Ra	nge 36E	NMPM Lea County	
		3878.6	Show whether i GR	DF, RKB, RT, GR, etc.)	(/////////////////////////////////////	
1.	Check A	TITE TO THE TOTAL THE TOTAL TO THE TOTAL TOT		Vature of Notice De	port, or Other Data	
N	IOTICE OF INT	ENTION TO:	moreage 1	Sure	SEQUENT REPORT OF:	
RFORM REMEC	DIAL WORK	PLUG AND ABAND	ION PER			
MPORARILY AB	BANDON []		(L)	REMEDIAL WORK	ALTERING CASING	
ULL OR ALTER CASING CASING TO				COMMENCE DRILLING	= 12011110 ABANDONNENT Y	
				CASING TEST AND CEMENT JCB		
THER:			LJ	OTHER:		
2. Describe Propos work) SEE RUI	ed or Completed Operation	ons (Clearly state all pertin	ent details, an	d give pertinent dates, includ	ing estimated date of starting any proposed	
3/05/92						
3/06/92	Pull tubing; Set CIBP @ 6600' w/2 sks cement on top. Circulate hole w/9.3# gelled brine & cut casing @ 5,000'. Could not pull casin					
	Cut casing @ 2800' (per OCD approval); LD 5 1/2" casing.					
3/07/92	LD 5 1/2" casing; Ran tubing to 2821'; Load hole w/brine and set 100 sk plug; Mix and set 50 sks cement plug from 1900 - 1800'.					
3/07/92 3/08/92	LD 5 1/27 car Mix and set	51 gks cement -	ng to 28	21'; Load hole	w/brine and set 100 sk plug;	
3/08/92		so and cement t	rug IIO	m 1900 - 1800.		
		nead; Set 10 sk	rug IIO	m 1900 - 1800.	w/brine and set 100 sk plug;	