

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

1. Type of Well <input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other	6. If Indian, Allottee or Tribe Name NM-40449
2. Name of Operator Siete Oil and Gas Corporation	7. If Unit or CA, Agreement Designation 9 06
3. Address and Telephone No. P.O. Box 2523, Roswell, NM 88202-2523	8. Well Name and No. Young N. 7 Fed. #1
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Sec. 7: T18S, R32E 2310' FNL & 1650' FEL SW 1/4 NE 1/4, Unit Letter G	9. API Well No. 30-025-30897
	10. Field and Pool, or Exploratory Area Undesignated
	11. County or Parish, State Lea, NM

CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent <input type="checkbox"/> Subsequent Report <input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Abandonment <input checked="" type="checkbox"/> Recompletion <input type="checkbox"/> Plugging Back <input type="checkbox"/> Casing Repair <input type="checkbox"/> Altering Casing <input type="checkbox"/> Other _____ <input type="checkbox"/> Change of Plans <input type="checkbox"/> New Construction <input type="checkbox"/> Non-Routine Fracturing <input type="checkbox"/> Water Shut-Off <input type="checkbox"/> Conversion to Injection <input type="checkbox"/> Dispose Water <small>(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)</small>

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Siete respectfully requests permission to test the Wolfcamp formation by doing the following procedure.

1. Install BOP, squeeze perfs @ 4545'-52' w/100 sxs "C".
2. DO squeeze & CIBP @ 5950'
3. Squeeze perfs @ 6178'-87' w/100 sxs "C".
4. DO squeeze & CIBP @ 6400'
5. Squeeze perfs @ 6780'-94' w/100 sxs "C".
6. DO squeeze & CIBP @ 7003'.
7. squeeze perfs @ 8218'-8520' w/200 sxs "C".
8. DO squeeze & CIBP @ 9050'.
9. Squeeze perfs @ 9126'-36' w/ 100 sxs "C".
10. DO squeeze & CIBP @ 9300'.
11. Set CIBP @ 10500'.
12. Perf 9635'-37' & 9642'-46'.
13. Acidized w/5000 gals 20% HCl.
14. Flow back & test.

14. I hereby certify that the foregoing is true and correct	
Signed <u>Cathy Bailey-Seely</u>	Title <u>Reg. Spec.</u> Date <u>6/2/93</u>
(This space for Federal or State office use)	
Approved by <u>DAVID B. GLASS</u>	Title _____ Date _____
Conditions of approval, if any:	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side