- 11/12/93 15 hr SITP 50 psi. IFL @ 10,800'. Made total of 8 swab runs & rec 2 BW & 1.5 BO.
- 11/13-17/93 Swabbed total of 4 BO & 6 BW in 3 days of swabbing. Each morning tagging FL @ 10,500'-11,000'. Getting 100-150' fluid entry every 1 1/2 hrs.
- 11/18/93 15 hr SITP 20 psi. Tag FL @ 11,500'. Pull 500' fluid, 50% oil. Released rig & SI well.