Dec. 1973	orm Approved.
UNITED STATES	Budget Bureau No. 42–R1424
	5. LEASE
DEPARTMENT OF THE INTERIOR	NM 12744
GEOLOGICAL SURVEY	
SUNDRY NOTICES AND REPORTS ON WELLS	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)	7. UNIT AGREEMENT NAME
reservoir. Use Form 9-331-C for such proposals.)	
1. oil gas	8. FARM OR LEASE NAME
well well attac	Tract 15
2. NAME OF OPERATOR	9. WELL NO.
	1
Anadarko Production Company	10. FIELD OR WILDCAT NAME
3. ADDRESS OF OPERATOR	
P.O. Box 806 Eunice, New Mexico 88231	Teas-Seven Rivers
 COCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.) 	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
AT SURFACE: 1980' FSL & 660' FEL AT TOP PROD. INTERVAL: & 660' FEL	<u>14, 205, 33E</u>
AT TOP PROD. INTERVAL: AT TOTAL DEPTH:	12. COUNTY OR PARISH 13. STATE
	Lea N. M
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	14. API NO.
REPORT, OR OTHER DATA	
	15. ELEVATIONS (SHOW DF, KDB, AND WD)
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:	3601' DF
FRACTURE TREAT	
SHOOT OR ACIDIZE	
	JAN 1 8 1985
PULL OR ALTER CASING	(NOTE: Report results of multiple completion or zone change on Form 9, 200)
	change on Form 9-330.)
(other)	
 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state including estimated date of starting any proposed work. If well is dir measured and true vertical depths for all markers and zones pertinent 1. RUPU TOH w/ 4¹/₂ injection PKR. (1-8-85) 	all pertinent details, and give pertinent dates, ectionally drilled, give subsurface locations and to this work.)*
 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 4. RU Reverse equipment & drill retainer (1-14-85) 5. TIH w/ cement retainer again & set @ 2994'. (1-15-85) 7. Tag plug @ 2989' & pump 280 SX Class H w/ 5# SX (left continuous column of set all set	Id not pump through retainer (1-12-85) 15-85) 2 15' cement on top of retainer 2 salt (1-16-85)
 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 4. RU Reverse equipment & drill retainer (1-14-85) 5. TIH w/ cement retainer again & set @ 2994'. (1-15-85) 7. Tag plug @ 2989' & pump 280 SX Class H w/ 5# SX (left continuous column of set all set	Id not pump through retainer (1-12-85) 15-85) 2 15' cement on top of retainer 2 salt (1-16-85)
 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 4. RU Reverse equipment & drill retainer (1-14-85) 5. TIH w/ cement retainer again & set @ 2994'. (1-15-85) 7. Tag plug @ 2989' & pump 280 SY Class W details 	Id not pump through retainer (1-12-85) 15-85) 2 15' cement on top of retainer 2 salt (1-16-85)
 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 4. RU Reverse equipment & drill retainer (1-14-85) 5. TIH w/ cement retainer again & set @ 2994'. (1-15-85) 7. Tag plug @ 2989' & pump 280 SX Class H w/ 5# SX (left continuous column of set all set	Id not pump through retainer (1-12-85) 15-85) 2 15' cement on top of retainer 2 salt (1-16-85)
 3. TIH w/ 3 3/4" bit & scraper & clean out to 3040 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 4. RU Reverse equipment & drill retainer (1-14-85) 5. TIH w/ cement retainer again & set @ 2994' (1-15-85) 6. Pump 50 SX Class H cement w/ 5# SX salt & leave (1-15-85) 7. Tag plug @ 2989' & pump 280 SX Class H w/ 5# SX (left continuous column of cement from retainer 8. Set dry hole marker. RDPU & clean location (1-15-85) 	Id not pump through retainer (1-12-85) 15-85) e 15' cement on top of retainer (salt (1-16-85) to surface) 17-85)
 3. TIH w/ 3 3/4" bit & scraper & clean out to 3040 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 4. RU Reverse equipment & drill retainer (1-14-85) 5. TIH w/ cement retainer again & set @ 2994' (1-15-85) 6. Pump 50 SX Class H cement w/ 5# SX salt & leave (1-15-85) 7. Tag plug @ 2989 & pump 280 SX Class H w/ 5# SX (left continuous column of cement from retainer 8. Set dry hole marker. RDPU & clean location (1- 	Id not pump through retainer (1-12-85) 15-85) e 15' cement on top of retainer (salt (1-16-85) to surface) 17-85)
 IIII w/ 3 3/4" bit & scraper & clean out to 3040 TIH w/ 4½" cement retainer & set @ 2994'. Coul RU Reverse equipment & drill retainer (1-14-85) TIH w/ cement retainer again & set @ 2994'. (1-15-85) Pump 50 SX Class H cement w/ 5# SX salt & leave (1-15-85) Tag plug @ 2989' & pump 280 SX Class H w/ 5# SX (left continuous column of cement from retainer Set dry hole marker. RDPU & clean location (1- 	Ld not pump through retainer (1-12-85) L5-85) e 15' cement on top of retainer (salt (1-16-85) to surface) 17-85) Set @Ft.
 IIII w/ 3 3/4" bit & scraper & clean out to 3040 TIH w/ 4½" cement retainer & set @ 2994'. Coul RU Reverse equipment & drill retainer (1-14-85) TIH w/ cement retainer again & set @ 2994'. (1-15-85) Pump 50 SX Class H cement w/ 5# SX salt & leave (1-15-85) Tag plug @ 2989' & pump 280 SX Class H w/ 5# SX (left continuous column of cement from retainer Set dry hole marker. RDPU & clean location (1- 	Ld not pump through retainer (1-12-85) L5-85) e 15' cement on top of retainer (salt (1-16-85) to surface) 17-85) Set @Ft.
 IIII w/ 3 3/4" bit & scraper & clean out to 3040 TIH w/ 4½" cement retainer & set @ 2994'. Coul RU Reverse equipment & drill retainer (1-14-85) TIH w/ cement retainer again & set @ 2994'. (1-15-85) Pump 50 SX Class H cement w/ 5# SX salt & leave (1-15-85) Tag plug @ 2989' & pump 280 SX Class H w/ 5# SX (left continuous column of cement from retainer Set dry hole marker. RDPU & clean location (1- 	Ld not pump through retainer (1-12-85) L5-85) e 15' cement on top of retainer (salt (1-16-85) to surface) 17-85) Set @Ft.
 3. TIH w/ 3 3/4" bit & scraper & clean out to 3040 3. TIH w/ 4½" cement retainer & set @ 2994'. Coul 4. RU Reverse equipment & drill retainer (1-14-85) 5. TIH w/ cement retainer again & set @ 2994' (1-15-85) 6. Pump 50 SX Class H cement w/ 5# SX salt & leave (1-15-85) 7. Tag plug @ 2989 & pump 280 SX Class H w/ 5# SX (left continuous column of cement from retainer 8. Set dry hole marker. RDPU & clean location (1- 	Id not pump through retainer (1-12-85) 15-85) 15' cement on top of retainer (salt (1-16-85)) to surface) 17-85) Set @Ft.

*See Instructions on Reverse Side

والوالا البلايا المعادة بطوافة المستقر

1

FEB -1 1985 O.C.O. HOESE OPPICE

;

RESEIVED