

J. S. LIA (a) WELL NO. 1

Fill the hole with heavy mud and spot a cement plug of 20 sacks from approximately 3536' to 3420' (in the bottom of the 6-1/4" casing). Part and pull 2900' of 6-1/4" casing, if possible. (above base of salt). Part and pull 1300' of 10" casing, if possible, and spot a cement plug of 25 sacks from approximately 1573' to 1473' (in the bottom of the 10" casing). Spot cement plugs--35 sacks from approximately 747' to 707' and 40 sacks from approximately 230' to 210'. Cement customary 4" pipe marker in the hole with 20 sacks. All mud and cement to be pumped in through tubing.

