

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes OIA
C-102 and C-101
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR NOTICES OR REPORTS ON WELLS IN A DIFFERENT RESERVOIR. USE APPROPRIATE FORM FOR WELLS IN THE FOLLOWING RESERVOIRS: (SEE RULE 1103)		5a. Indicate Type of Lease State ☒ Fee ☐ 5. State Oil & Gas Lease No.
1. Name of Operator Sun Oil Company 2. Address of Operator P. O. Box 1861 - Midland, TX 79702 3. Location of Well UNIT LETTER L 661.1 FEET FROM THE West LINE AND 1985.3 FEET FROM THE South LINE, SECTION 24 TOWNSHIP 19S RANGE 36E NEPTIS.		7. Unit Agreement No. 8. Former or Lease Name J. L. Barr 9. Well No. 2 10. Field and Pool, or oil zone Eumont Gas
11. Elevation (Show whether DF, RT, GR, etc.) 3688.5 GR		12. County LEA

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK ☐ TEMPORARILY ABANDON ☐ PULL OR ALTER CASING ☐ OTHER Bradenhead has 160# pressure and bleeds saltwater-Repair csg Leak ☒		SUBSEQUENT REPORT OF: PLUG AND ABANDON ☐ CHANGE PLANS ☐ OTHER ☐ REMEDIAL WORK ☐ COMMENCE DRILLING OPNS. ☐ CASING TEST AND CEMENT JOBS ☐ OTHER ☐ ALTERING CASING ☐ PLUG AND ABANDONMENT ☐	
---	--	---	--

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU. Kill well w/2% KCL water and .1% Morflo.
2. Install BOP. POH w/tbg & pkr. (Inspect & replace if necessary)
3. RIH w/full bore pkr, SN & RBP to 3550'. Set RBP, test csg to 1000#. Reset RBP @ 1400'. POH w/pkr.
4. GOI perf 4 way squeeze shot @ 1200'.
5. Run full bore pkr, SN on 2-3/8 work string. Set pkr @ 900' and attempt to break circ out bradenhead.
6. HOWCO pump 300 sx Class C w/2% CaCl₂. If cmt cir, close valve & squeeze w/rest of cmt. Displace to 1150' S.D. & hold pressure 1 hr. POH.
7. Drill out to RBP, pressure & swab test squeeze. Check BH for pressure build up. If OK, continue, otherwise call Midland for instructions.
8. Retrieve RBP, rerun prod. pkr, tbg & SN. Swab well in. RD RR.

THE COMMISSION MUST BE NOTIFIED
24 HOURS PRIOR TO COMMENCING WORK

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Signed By <i>Carson Munzel</i> Original Signed By John Runyan Geologist	TITLE Production Staff Associate TITLE Geologist	DATE 12/6/78 DATE DEC 12 1978
--	--	---