

Form C-103
McGrail State Well No. 1
February 27, 1979
Page 2

17. Describe Proposed or Completed Operations (Cont'd)

11. Run in hole with retrieving tool on tubing. Swab well dry. Sting onto bridge plug and pull out of hole with tubing and bridge plug.
12. Run in hole with 2 7/8" tubing bowl on tubing, latch over cut-off joint, and set in tension.
13. Remove BOP's and install tree.
14. Rig up wireline service. Retrieve tubing plug.
15. Place well on production. Monitor 9 5/8" casing for pressure buildup.