

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Aztec, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-04168
5. Indicate Type of Lease	STATE ☒ FEE ☐
6. State Oil & Gas Lease No.	A-1375-39
7. Lease Name or Unit Agreement Name	NORTH MONUMENT G/SA UNIT BLK. 18
8. Well No.	7
9. Pool name or Wildcat	EUNICE MONUMENT G/SA

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER ☐	2. Name of Operator AMERADA HESS CORPORATION
3. Address of Operator POST OFFICE DRAWER D, MONUMENT, NEW MEXICO 88265	
4. Well Location Unit Letter G : 1980 Feet From The NORTH Line and 1980 Feet From The EAST Line	

Section 2	Township 20S	Range 36E	NMMPM	LEA	County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)					

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐
PULL OR ALTER CASING ☐	OTHER: Convert to injection well. ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐	ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐	PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐	OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

NMGSAU #1807

R-95596

Move in and RU pulling unit, reverse unit and air unit. ND wellhead. TOH and lay down rods and pump. ND wellhead. NU BOP. TOH w/tbg. TIH w/RBP and set at $\pm 500'$. Install new wellhead equipment. Retrieve RBP. TIH w/bit, drill collars and tbg. Clean out to TD at 3,912' and deepen openhole to 3,965'. TOH w/bit. TIH w/underreamer. RD air unit. RU Schlumberger and log the openhole w/Sonic/LDT/CNL/GR tools. Evaluate logs for additional perforations. Perforate as needed. RD Schlumberger. TIH w/a sonic hammer on tbg. to TD. RU acid co. Acidize well w/5,000 gals. 15% NEFE DI HCL w/3% DP-77MX Micellar Solvent. TOH w/sonic hammer. TIH w/tbg. and pkr. Set pkr. at $\pm 3,700'$. Swab/flow back load. TOH w/tbg. & pkr., laying down production tbg. Pick up and TIH w/2-3/8" lined injection tbg. w/inj. pkr. ND BOP. NU injection wellhead assembly. RD and move out pulling unit. Clean and clear location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry L. Harvey TITLE Sr. Staff Assistant DATE 03-22-95

TYPE OR PRINT NAME Terry L. Harvey TELEPHONE NO. 393-2144

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

MAR 28 1995