

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
2. Name of Operator Continental Oil Company	5. State Oil & Gas Lease No.
3. Address of Operator P. O. Box 460, Hobbs, New Mexico 88240	7. Unit Agreement Name
4. Location of Well UNIT LETTER <u>8</u> <u>2310</u> FEET FROM THE <u>South</u> LINE AND <u>2310</u> FEET FROM THE <u>West</u> LINE, SECTION <u>10</u> TOWNSHIP <u>20S</u> RANGE <u>36E</u> NMPM.	8. Farm or Lease Name Reed Sanderson Unit
	9. Well No. 24
	10. Field and Pool, or Wildcat Eumont Pool
15. Elevation (Show whether DF, RT, GR, etc.) 3595 D.F.	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	
OTHER <u>Convert to Water Injection</u> <input checked="" type="checkbox"/>	

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
OTHER <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

In connection with the Reed Sanderson Unit Waterflood, it is proposed to convert the subject well to water injection using the following procedure:

1. Tag bottom and clean out if fill exists.
2. Run cement-lined tubing w/packer set at approximately 3700'.
3. Connect up well and commence water injection down tubing.

NMOCC Order R-3131 was issued on September 28, 1966, authorizing institution of the Reed Sanderson Unit Waterflood.

A subsequent report will be submitted upon completion of this work.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jesse D. Stork TITLE Supervising Engineer DATE 5-5-67

APPROVED BY _____ TITLE _____ DATE _____