

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well ☒ Oil Well ☐ Gas Well ☐ Other	5. Lease Designation and Serial No. <u>LC-031622A</u>
2. Name of Operator <u>Conoco Inc.</u>	6. If Indian, Allottee or Tribe Name
3. Address and Telephone No.	7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)	8. Well Name and No. <u>Sanderson A No. 12</u>
	9. API Well No. <u>30-025-04266</u>
	10. Field and Pool, or Exploratory Area <u>Cumant Gate 7 Rurs. Queen</u>
	11. County or Parish, State <u>Lea</u>

12 CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
☐ Notice of Intent	☐ Abandonment
☒ Subsequent Report	☐ Recompletion
☐ Final Abandonment Notice	☐ Plugging Back
	☐ Casing Repair
	☐ Altering Casing
	☒ Other <u>Squeeze Queen perf</u>
	☐ Change of Plans
	☐ New Construction
	☐ Non-Routine Fracturing
	☐ Water Shut-Off
	☐ Conversion to Injection
	☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1-23-91 Co fill, cmt = CIBP from 3730 - 3801. Fell free. GIH + tag up at 3820. Do metal + scale from 3820 to 3825. SDON.

1-24-91 Tag up at 3769 (52' high). Drill on aluminum liner from 3769 - 3773. Do liner from 3730 - 3777.

1-25-91 Do 4" liner from 3737 - 3760.

1-26-91 Mill out liner from 3760 - 3786. SDOWE.

1-28-91 Do liner from 3786 - 3820.

1-29-91 Drill on liner from 3820 - 3830. Started drilling in junk iron. Unable to make any hole. POH w/ tbg + tools. Ream out hole from 3786 - 3830. Prep to mill on junk.

1-30-91 Mill out junk iron from 3830 - 3836.

1-31-91 GIH w/ 4 3/4" bit. Do liner from 3836 - 3864.

2-1-91 Do liner from 3864 - 3868. Do liner from 3868 - 3870. Do CIBP at 3870. Do liner from 3872 - 3879. (Cont)

14. I hereby certify that the foregoing is true and correct

Signed Vanetta Wilson

Title Analyst - Oil Production

Date 3-15-91

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date