

*Summarized Workover Procedure:*

This workover was designed to replace an existing pump with a larger pump in order to produce more fluid. Ultimately, the excess water will be pumped off and an increase in oil production will occur.

- 1) MIRU pulling unit.
- 2) POH with rods and pump.
- 3) RIH with new pump and rods.
- 4) Space out and clamp off.
- 5) Hang well on. RD pulling unit.
- 6) Test pump and put back on production
- 7) Notify field office personnel of well status.