(November 1983) (Formerly 9-331) DEPART	L TED STATES SUBMIT IN	Form approved Budget Bureau No. 1004-0135 Expires August 31, 1985
BURE	TMENT OF THE NTERIOR (Other lastru EAU OF LAND MANAGEMENT	5. LEASE DESIGNATION AND SERIAL NO.
SUNDRY NO (Do not use this form for prop Use "APPLI	OTICES AND REPORTS ON WELLS possais to drill or to deepen or plug back to a different res GATION FOR PERMIT—" for such proposals.)	LC-031736-A 6. IF INDIAN, ALLOTTEE OR TRIBE NAME servoir.
i. OIL GAR	tot auch proposals.)	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR		Eunice Monument Sout
Chevron U.S.A. Inc.		8. FARM OR LEASE NAME UNIT
P.O. Box 670 Hobbs Nov	w Mexico 88240 clearly and in accordance with any State requirements.*	9. WELL NO. 103
660' FNL and 1980		10. FIELD AND FOOL, OR WILDCAT Eunice Monument G/SA 11. SEC., T., R., M., OR BLK, AND SURVEY OR AREA
4. PERMIT NO.	15. ELEVATIONS (Show whether DF, ET, GR, etc.)	Sec.25,T20S,R36E
	3552	12. COUNTY OF PARISH 13. STATE Lea NM
s. Check A	ppropriate Box To Indicate Nature of Notice, R	sport, or Other Data
THE TAILS	TION TO:	SUBSEQUENT REPORT OF:
PEACTURE TREAT SHOOT OR ACIDIZE	PULL OR ALTER CASING WATER SHUT-OF MULTIPLE COMPLETE FRACTURE TREAT ABANDON® SHOOTING OR AC	TMENT ALTERING CARING
(Other)	(Norr · D.	on, log,
. DESCRIBE PROPOSED OR COMPLETED OPER proposed work. If well is direction	Completion RATIONS (Clearly state all pertinent details, and give pertinent details, and measured and	or Recompletion Report and Log form.)
ment to this work) *	drined, give subsurface locations and measured and	true vertical denting estimated date of starting any
TD: POOH w/ production new 6 1/8" hole f/	4005 equipment. Establish circula 3870 to 4005 Circulate hal	ation w/air mist. Drlg.
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam.	4005 equipment. Establish circula 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Cal uction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, O PU. Leave well numping	ation w/air mist. Drlg. e clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD Mo	4005 equipment. Establish circula 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Cal uction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, O PU. Leave well numping	ation w/air mist. Drlg. e clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD Mo	4005 equipment. Establish circula 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Cal uction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, O PU. Leave well numping	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD Mo	4005 equipment. Establish circula 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Cal uction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, O PU. Leave well numping	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD Mo	4005 equipment. Establish circula 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Cal uction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, O PU. Leave well numping	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD McWork performed, 5-9	equipment. Establish circular and to 4005. Circulate hole Log with CNL-GR-CCL and Calluction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, OPU. Leave well pumping. To 5-88 thru 5-9-88	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD Mo	equipment. Establish circular 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Calluction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, OPU. Leave well pumping. To 5-88 thru 5-9-88	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD MC Work performed, 5-1	equipment. Establish circular 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Calluction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, OPU. Leave well pumping. T5-88 thru 5-9-88	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.
POOH w/ production new 6 1/8" hole f/ 8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD Mowork performed, 5-1 This space for Federal or State office to the space for Federal or S	equipment. Establish circular 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Calluction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, O PU. Leave well pumping. To 5-88 thru 5-9-88	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.
POOH w/ production new 6 1/8" hole f/8.6 CKF on bottom. RIH w/ 2 7/8" Product, hang on beam. up location. RD Mowork performed, 5-19 Work performed, 5-19 This space for Federal or State office of the space for Federal or State of the space for Federal or State office of the space for Federal or State of the space for Fe	equipment. Establish circular 3870 to 4005. Circulate hole Log with CNL-GR-CCL and Calluction tbg. (6.5#, 8rd, EUE,) Load and test tbg and pump, O PU. Leave well pumping. To 5-88 thru 5-9-88	ation w/air mist. Drlg. clean. Spot 50bbls liper from 3991 to surface. EOT 3994'. Space 500psi, ok. Clean Furn over to production.