Submit 3 Copies to Appropriate

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

District Office OIL CONSERVATION DIVISION DISTRICT I WELL API NO. P.O. Box 1980, Hobbs NM 88241-1980 P.O. Box 2088 30-025-05644 Santa Fe, New Mexico 87504-2088 P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease STATE FEE X DISTRICT III 6. State Oil & Gas Lease No. 1000 Rio Brazos Rd., Aztec, NM 87410 SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) NORTH MONUMENT G/SA UNIT Type of Well: BLK. 5 οίι well X WELL OTHER 2. Name of Operator 8. Well No. Amerada Hess Corporation 3. Address of Operator 9. Pool name or Wildcat P..O. Box 840, Seminole, Texas 79360 EUNICE MONUMENT G/SA 4. Well Location 1980 NORTH 1980 Unit Letter Feet From The Line and **EAST** Feet From The Line 19 37E LEA Section Township Range **NMPM** County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 11 Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data **NOTICE OF INTENTION TO:** SUBSEQUENT REPORT OF: PLUG AND ABANDON PERFORM REMEDIAL WORK REMEDIAL WORK ALTERING CASING **TEMPORARILY ABANDON CHANGE PLANS** COMMENCE DRILLING OPNS PLUG AND ABANDONMENT PULL OR ALTER CASING CASING TEST AND CEMENT JOB CONVERT TO INJECTION WELL. OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. NMGSAU #507 Permit No. WFX716 MIRU PU. TOH W/RODS (LAYING DWN). NU BOPS & TOH W/TBG. TIH W/TBG. & 5-1/2" RBP. SET BELOW 3,500'. CIRC. WELL & TST. CSG. ND OLD WELLHEAD. INSTALL NEW INTEGRAL WELLHEAD. TIH W/TBG., COLLARS & BIT. TAG TD @ 3,988'. TOH W/TBG. MIRU SCHLUMBERGER. RUN GR/CNL/BHC LOG FR./TD TO MIN. FOOTAGE. EVALUATE LOGS TO DETERMINE TOP OF Z7 (EST. @ 3,925'). PLUG BACK W/CMT. TO TOP A7. SWAB TO DETERMINE SAN ANDRES INFLOW. RUN SBHP. TIH W/TBG. & SONIC HAMMER. TREAT O.H. W/8,000 GALS. ACID. FLOW/SWAB BACK LOAD. MONITOR FL FOR SAN ANDRES INFLOW. TOH W/TBG. (LAYING DWN.) TIH W/INJ. PKR. & TBG. NU WELLHEAD. MAKE WELL READY FOR INJ. I hereby certify that the information above is true and complete to the hest of my knowledge and belief. TITLE SR. STAFF ASSISTANT DATE 7-17-97 TYPE OR PRINT NAME TERRY TELEPHONE NO. 915 758-6700 (This space for State Use) OIL & GAS INSPECTOR