Submit 3 Copies to Appropriate District Office

Energy, Minerals and Natural Resources Departmen

Form	C-103
Revis	rd 1-1-49

P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 P.O. Drawer DD, Artesia, NM 88210 DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410 P.O. Box 2088 Santa Fe, New Mexico 87504-2088 Santa Fe, New Mexico 87504-2088 STATE X FEE	
P.O. Drawer DD, Artesia, NM 88210 Salita Fe, New Mexico 8/504-2088 5. Indicate Type of Lease	
DISTRICT III	
(Com 0.1 v 2 v 2 v 2 v 2 v 2 v 2 v 2 v 2 v 2 v	
a. State Oil & Gas Lease No.	
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 7. Lease Name or Unit Agreement Name	
1. Type of Well:	
OF THE TOTAL OTHER NORTH MONUMENT G/SA UNIT	
2. Name of Operator BLK, 11	
AMERADA HESS CORPORATION	
3. Address of Operator POST OFFICE DRAWER D, MONUMENT, NEW MEXICO 88265 2 9. Pool name or Wildcat EUNICE MONUMENT G/SA	
- Weil LUCALOR	
Unit Letter B: 660 Feet From The NORTH Line and 1980 Feet From The EAST	Line
Section 20 To 1 100 - 077	706
10 Elevation (Show whether DF, RKB, RT, GR, etc.)	77
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	!
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING	Г
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT	
PULL OR ALTER CASING CASING TEST AND CEMENT JOB	_
OTHER: RUN LINEY \ OTHER:	
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.	
work) SEE RULE 1103.	
NMGSAU #1102	
NMGSAU #1102 Plan To	
Plane To Move in and rig up pulling unit. Change out wellhead. Remove scap liner located at	
Plan To Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as peopled	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 34630' to surface? Run production equipment. Rig down pulling	
Plan To Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as peopled	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 34630' to surface? Run production equipment. Rig down pulling	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 34630' to surface? Run production equipment. Rig down pulling	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 34630' to surface? Run production equipment. Rig down pulling	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 34630' to surface? Run production equipment. Rig down pulling	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 34630' to surface? Run production equipment. Rig down pulling	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 3,630' to surface. Run production equipment. Rig down pulling unit. Clean location and resume prod. well.	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 3,630' to surface: Run production equipment. Rig down pulling unit. Clean location and resume prod. well.	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 3,630' to surface. Run production equipment. Rig down pulling unit. Clean location and resume prod. well. Thereby certify that the information above is true and complete to the best of my knowledge and belief. Signature	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 3;630' to surface. Run production equipment. Rig down pulling unit. Clean location and resume prod. well. I bereby certify that the information above is true and complete to the bost of my knowledge and belief. SKONATURE	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 3;630' to surface. Run production equipment. Rig down pulling unit. Clean location and resume prod. well. I bereby certify that the information above is true and complete to the bost of my knowledge and belief. SKONATURE	
Move in and rig up pulling unit. Change out wellhead. Remove scab liner located at 2,270' to 2,570'. Locate and determine extent of casing leaks. Repair as needed. Run a 4-1/2" liner to 3,630' to surface. Run production equipment. Rig down pulling unit. Clean location and resume prod. well. Thereby certify that the information above is true and complete to the best of my knowledge and belief. Signature	=

RECEVED

0

FES 6 8 199**4**

OCT HOBBS OFFICE