

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.	30-025-05761
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	NORTH MONUMENT G/SA UNIT BLK. 15
8. Well No.	7
9. Pool name or Wildcat	EUNICE MONUMENT G/SA

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL  GAS WELL  OTHER

2. Name of Operator  
AMERADA HESS CORPORATION

3. Address of Operator  
POST OFFICE DRAWER D, MONUMENT, NEW MEXICO 88265

4. Well Location

Unit Letter G : 1980 Feet From The NORTH Line and 1980 Feet From The EAST Line

Section 31 Township 19S Range 37E NMZM LEA County

10. Elevation (Show whether DF, R/B, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: Intent to convert to Injection Well. <input checked="" type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

NMGSAU #1507

Move in and rig up pulling unit and reverse unit. TOH with rods and pump. Nipple Down wellhead. Nipple up BOP. TOH with tubing laying down. Rig up Schlumberger and log the openhole with CNL/GR tools. Add perforations based on new logs. Rig down Schlumberger. TIH with treating packer on tubing to +/- 3,750'. Load casing-tubing annulus with fresh water. Set packer. Rig up acid company. Acidize well with 3,000 gals. 15% NEFE DI HCL w/3% DP-77MX Micellar solvent (using rock salt as diverting agent as needed). Swab/flow back load. TOH w/tubing and packer, laying down production tubing. Pick up and TIH w/2 3/8" coated injection tubing w/injection packer. Nipple down BOP. Nipple up injection wellhead assembly. Rig down and move out pulling unit. Clean and clear location.

I hereby verify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry L. Harvey TITLE Staff Assistant DATE 10-24-94

TYPE OR PRINT NAME Terry L. Harvey TELEPHONE NO. 393-2144

(This space for State Use)

**OCT 28 1994**

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: