

Attachment C-102

Gulf Oil Corporation, B. V. Culp (NCT-B) well no. 4, Section 31, 19-S, 37-E,  
Lea County, New Mexico.

6. Close in well overnight.
7. Swab and test perfs 5637-85'. Kill well, release packer and pick up BP. Swab and test all perfs together.
8. Kill well. Pull tubing and straddle tools.
9. Run 2-3/8" OD 4.70# tubing. Install down hole pumping equipment, if necessary, and place well on production.

Measurement 2-102  
 1111 1/2 Corporation, 81 V. Ave. (100-2) well no. 1, Section 31, 12-2, 31-1  
 100-2, 31-1

1. Run 2-3/8" or 1-1/2" tubing. Install down hole pumping equipment, if necessary, and place well on production.
2. Kill well. Fill tubing and standing tools.
3. Shut and test all perforations.
4. Swap and test perforations 2031-211. Kill well, release packer and pick up.
5. Place in well overnight.