

|                        |  |
|------------------------|--|
| NO. OF COPIES RECEIVED |  |
| DISTRIBUTION           |  |
| SANTA FE               |  |
| FILE                   |  |
| U.S.G.S.               |  |
| LAND OFFICE            |  |
| OPERATOR               |  |

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

|  |  |
|--|--|
| 1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>   | 7. Unit Agreement Name                                   |
| 2. Name of Operator<br><b>John H. Hendrix</b>  | 8. Farm or Lease Name<br><b>Cooper B</b>                 |
| 3. Address of Operator<br><b>316 Central Bldg., Midland, Texas 79701</b>   | 9. Well No.<br><b>12</b>                                 |
| 4. Location of Well<br>UNIT LETTER <b>D</b> , <b>330</b> FEET FROM THE <b>North</b> LINE AND <b>330</b> FEET FROM<br>THE <b>West</b> LINE, SECTION <b>7</b> TOWNSHIP <b>20S</b> RANGE <b>37E</b> NMPM. | 10. Field and Pool, or Wildcat<br><b>Monument (G-SA)</b> |
| 15. Elevation (Show whether DF, RT, GR, etc.)  | 12. County<br><b>Lea</b>                                 |

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS ☐ PLUG AND ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐ OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### PROPOSED REMEDIAL WORK

1. Set Halliburton cement retainer at 3680'. Squeeze perforations 3695-3712 w/200 sxs cement containing 3/10 of 1% Halad-9.
2. Perforate at 3432, 3449, 3462, 3513, 3530, 3568, 3594, 3609, 3643 & 3652½ with 1-3/8" jet shot per interval.
3. Acidize w/5000 gallons 15% LSTNE acid.
4. Swab and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John H. Hendrix TITLE Owner-Operator

DATE 1/28/71

APPROVED BY [Signature]  
CONDITIONS OF APPROVAL, IF ANY:

TITLE

**SUPERVISOR DISTRICT**

DATE

**FEB 1 1971**