

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.B.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name S. E. Cone - Will Terry
9. Well No. 1
10. Field and Pool, or Wildcat Hobbs GSA
12. County Lea

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - 1" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- PXA
2. Name of Operator AMOCO PRODUCTION COMPANY
3. Address of Operator P. O. Box 68, Hobbs, NM 88240
4. Location of Well UNIT LETTER 0 990 FEET FROM THE South LINE AND 1650 FEET FROM THE East LINE, SECTION 9 TOWNSHIP 19-S RANGE 38-E N.M.P.M.
15. Elevation (Show whether DF, RT, GR, etc.) 3611' GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to re-plug the subject well as follows due to NMOCD ruling:  
Cut off cap and permanent abandonment marker to re-enter well. Tag plug back TD at 1850' and circ. heavy mud from the hole with fresh water. Run freepoint log to determine top of free cement. If possible, cut the 5-1/2", 15# casing at 500' (cut as deep as possible to salt) and pull the casing. If freepoint is above 500', cut the casing one joint above the freepoint and pull casing. Spot 140 sacks class C neat cement 500' to surface. Weld on cap and erect PXA marker. (Notify NMOCD prior to setting plugs.)

0+5-NMOCD,H 1-R. E. Ogden, HOU Rm. 21.150 1-F. J. Nash, HOU Rm. 4.206 1-CLF

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Cathy L. Ferman</u>	TITLE <u>Assist. Admin. Analyst</u>	DATE <u>3-23-84</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE <u>MAR 27 1984</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED  
MAR 26 1984  
0200  
HOBBS