

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPL
(Other instructions
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 065649

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

South Pearl Queen

FARM OR LEASE NAME

South Pearl Queen Unit

9. WELL NO.

26

10. FIELD AND POOL, OR WILDCAT

Pearl Queen

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

9-20S-35E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER Water Injection Well	
2. NAME OF OPERATOR Tamarack Petroleum Co., Inc.	
3. ADDRESS OF OPERATOR P. O. Box 2046; Midland, TX 79702	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1988 FWL & 1194.4 FNL Section 9, T20S R35E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3701.9 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	(Other) <input type="checkbox"/>
(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)			
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*			

PLUG AND ABANDON NO LONGER NECESSARY WATER INJECTION WELL

1. Move in and rig up plugging unit on/or about May 1, 1985
2. Unset Baker AD-1 tension Packer and pull out of hole.
3. Set CIBP at + 4950 (Perfs 5027-35), Pump 5 sacks cement on plug
Fill hole with 9.5# mud.
4. Cut 4 1/2" casing at 3590' (B/salt 3540') and pull out and lay down.
5. Pump 200' cement plug from 3690 to 3490. Tag plug
6. Pump 200' cement plug from 2100 to 1900 (T/anhydrite 1995) tag plug
7. Pump 100' cement plug from 264 to 164 (B/8 5/8" CSG @ 214') tag plug
8. Set 10 sacks cement surface plug and marker
9. Clean location

18. I hereby certify that the foregoing is true and correct		
SIGNED <u>Stanley L. Mulloy</u>	TITLE <u>Engineering Manager</u>	DATE <u>4/17/85</u>
(This space for Federal or State use)		
APPROVED BY _____	TITLE _____	DATE <u>7-8-85</u>
CONDITIONS OF APPROVAL, IF ANY:		

**Subject to
Like Approval
by State**

*See Instructions on Reverse Side

RECEIVED
APR 16 1985
FBI - NEW YORK
100-111111