

SUNDRY NOTICE
OCC Form C-103
N. M. "SL" St. Comm. #1
10-11-78

Page 2

9. Pull tbg to 2240' (Base Salt) and spot a 55 sx plug of Class "H" neat cmt.
10. Pull tbg to 1533' (Top Salt) and spot a 55 sx plug of Class "H" neat cmt.
11. Place a 10 sx plug at surface with marker 4' high showing operator and well location.
12. Dismantle surface installation and restore surface.