

Theodore Anderson Com #13

P&A Procedure

Page 2

15. Allow 48 hours for ZONITE to hydrate, remove WH, cut off casings 3' below GL and cap wellbore.
16. Install dry hole marker stamped w/ required well identification, 4" OD x 4' above GL.
17. Remove all equip and cut deadmen below GL.
18. Turn over to Chevron for any surface remediation work.

Estimated ZONITE Requirements: **114 ft³**