

Proposal to Plug & Abandon Continued:

10. Remove csg head equipment.
11. Set dry hole marker.
12. Fill cellar. Clean & clear location.

NOTE: Well originally completed as a Morrow gas well. Plugged back and completed in Bone Springs formation which was non-productive. Plugged back and completed in Brushy Canyon formation which is no longer economical.