

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division  
P.O. Box 1980  
Hobbs, NM 88241

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well  
☐ Oil Well ☐ Gas Well ☒ Other Dry Hole

2. Name of Operator  
Stevens & Tull, Inc.

3. Address and Telephone No.  
P.O. Box 11005, Midland, TX 79702 915/699-1410

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
660' FEL and 1650' FSL  
Section 17, T20S, R36E

5. Lease Designation and Serial No.  
NMLC046164-B

6. If Indian, Allottee or Tribe Name  
N/A

7. If Unit or CA, Agreement Designation  
N/A

8. Well Name and No.  
Amerada Federal #3

9. API Well No.  
30-025-27132

10. Field and Pool, or Exploratory Area  
Wildcat

11. County or Parish, State  
Lea, NM

CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other P&A Wellbore

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completions on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

5/8/97 - MIRU Pulling unit - Start P&A Procedures - set CIBP at 5700'.

5/9/97 - RIH with tubing and spot 35 sx cement on top of CIBP at 5700'. Mix mud and circulate hole with 9.8 ppg drilling mud.

5/10/97 - Shoot off 7" casing at 3600' - POH laying down casing. Set 65 sx cement plug at 3650'. SDFWE

5/12/97 - Tag cement plug at 3528' - BLM witnessed all plugs - set 100 sx plug at 3020' - 2920' - set 50 sx plug from 1315' - 1415' - set 25 sx plug at surface.

5/13/97 - Install dry hole marker - clean location and level pits - ready for final inspection.

Approved as to contents of this well bore  
by \_\_\_\_\_  
Title \_\_\_\_\_

14. I hereby certify that the foregoing is true and correct

Signed Alexis C. Swoboda

Title Consulting Engineer

Date 5/29/97

(This space for Federal or State office use)

Approved by (ORIG. SGD.) ALEXIS C. SWOBODA

Title PETROLEUM ENGINEER

Date JUN 10 1997

Conditions of approval, if any: