

## CEMENTING RECORD

- 13 3/8" Casing - Cemented with 255 sacks Western Lite & 250 sacks class "C"  
Circulated
- 8 5/8" Casing - Cemented 1st stage with 1200 sacks pace setter lite( $\frac{1}{4}$ #  
permacheck/sack & 5# salt/sack) and 2nd stage with 250  
sacks class "C" neat - did not circulate - set RTTS packer  
and cement with 1400 sacks thick-o-mite - did not circulate -  
finish cementing with 4400 sacks of Pacesetter lite -  
Circulated.
- 5  $\frac{1}{2}$ " Casing - Cemented first stage with 1725 sacks class "H" + 2% Cal. Chloride  
+ 2% AFS - DV tool @ 8,036'. Second stage with 600 sacks  
Pacesetter lite class "C" + 150 sacks premium Class "C"  
Circulated.