

CASING AND CEMENT PROGRAM:

The casing and cementing programs are detailed on Form 3160-3. All casing will be new.

Centralizer Program:

Surface Casing - Centralize the bottom 3 joints and every 4th to surface.

Production Casing - Centralize every other joint on bottom 600'.

MUD PROGRAM:

<u>Depth</u>	<u>Type</u>	<u>Weight</u>	<u>Viscosity</u>
0'-425'	Fresh Water	8.4	28
425'-1000'	Fresh Water	8.4	28
1000'-2940'	Brine	10.0	29
2940'-3740'	Brine/Starch	10.0	32

LOGGING, TESTING:

SGR-SD-DSN and GR-DLL-MSFL-CSL surveys will be run.

No Mud Logging Unit will be used.

No drill stem tests will be conducted.

No cores will be taken.