

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <u>Water Injection Well</u>		7. Unit Agreement Name <u>SKAGGS GRAYBURG UNIT</u>
2. Name of Operator <u>TEXACO Inc.</u>		8. Farm or Lease Name <u>SKAGGS GRAYBURG UNIT</u>
3. Address of Operator <u>P. O. Box 728, Hobbs, New Mexico 88240</u>		9. Well No. <u>1</u>
4. Location of Well UNIT LETTER <u>K</u> <u>1985</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>12</u> TOWNSHIP <u>20-S</u> RANGE <u>37-E</u> NMPM.		10. Field and Pool, or Wildcat <u>SKAGGS GRAYBURG</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>3569' (DF)</u>		12. County <u>Lea</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Repair Water Flow</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install BOP. Pull tubing & pkr.
2. Set RBP @ 3000' & spot 20' sand on plug.
3. Perforate 7 5/8" csg W/2-JS @ 1489'.
4. Set cement retainer @ 1390'. Cement to surface W/250 sx. class 'H' cement. Squeeze W/addl. 200 sx. class 'H' cement. WOC. DOC. TEST.
5. Install injection equipment. Return to Injection

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Jerry Sexton</u>	TITLE <u>Asst. Dist. Mgr.</u>	DATE <u>7-27-83</u>
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR		
APPROVED BY _____	TITLE _____	DATE <u>JUL 28 1983</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED  
JUL 27 1983  
O.C.D.  
HOBBY OFFICE