

Continued

12. Set RBP @ 5250' and packer @ 5225'. Acidized Glorieta perforations 5280'-5296' w/2000 gals. 15% NE Acid in 2-1000 gal. Stages using 500# Rock Salt between stages. Flush w/30 bbl fresh water.
13. Install pumping equipment. Test as Downhole Commingle at Glorieta and Drinkard Zones. On 24 Hr. PT ending 3-13-76. Well pumped 30 BO and 127 BW. GOR 8000.