

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)

Form approved.  
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. LC 031620 b
2. NAME OF OPERATOR Continental Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR Box 460, Hobbs, New Mexico 88240		7. UNIT AGREEMENT NAME N.M.P.U.
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FSL and 660' FEL of Sec. 13, T-20S, R-37E, Lea County, New Mexico, N.M.P.M.		8. FARM OR LEASE NAME SEMU Permian
14. PERMIT NO.		9. WELL NO. 78
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3557 D.F.		10. FIELD AND POOL OR WILDCAT NMFU Field
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 13 - 20S - 37E
		12. COUNTY OR PARISH Lea
		13. STATE N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON\*

REPAIR WELL

CHANGE PLANS

(Other) Convert to Injection

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT\*

(Other)

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

It is proposed to convert the above subject well to injection, in connection with the Skaggs Pool Waterflood using the following procedure:

1. Rig up, pull rods & tubing.
2. Inject water down casing until well pressures up.
3. Cleanout to T. D. (3882). Deepen 43' to 3925'.
4. Run cement-lined tubing with injection packer set @ 3646'.
5. Resume injection.

A subsequent report will be submitted upon completion.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Staff Supervisor

DATE 4-10-67

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

USGS-5 PAN AM-Hobbs-2

ATL-Ros-2

CALIF-Mid-3

FILE-2

\*See Instructions on Reverse Side