

38. Release 7" treating packer @ +5550'.
 - A. Release 7" RBP @ +5950'.
 - B. POOH w/2-7/8" workstring, 7" treating packer & 7" RBP.
39. Rig up wireline unit & RIH w/7" permanent packer & set @ 6585'.
40. RIH w/2-3/8" Drinkard tbg, 2-3/8" Blinebry-Tubb tbg, & 1-1/4" vent string.
 - A. Land Drinkard SN @ +6850' w/ SOPMA @ +6880'.
 - B. Land Blinebry-Tubb SN @ +6545' w/SOPMA @ +6575'.
NOTE: Externally Push the Cont Drinkard & Vent string tubing below the short string.
NOTE: Use Otis large bore vent head assembly and special parallel anchor. *SK*
- NOTE: Spot 66 gals Cortron RH-67 (Champion) weighted corrosion inhibitor in dead space between permanent packer & Blinebry-Tubb seating nipple.
41. RIH w/Drinkard & Blinebry-Tubb dip tubes, rods & pumps.
42. Hang on Blinebry-Tubb side and return to production.
43. Install test pumping unit and test pump Drinkard side.