

Scope of Work - Deepening To Abo:

1. Pull existing completion (rods and tubing)
2. Squeeze off Blinbry and Tubb perfs
3. Drill out and test Blinbry and Tubb perfs
4. Deepen well to 7400'. POOH LD DP
5. Run open hole logs
6. Run 5" flush joint liner and tie back into 7" casing. Cement liner into place
7. Drill out liner top and dress off
8. Spot acid across Abo interval
9. Perforate Abo formation
10. Run packer and tubing. Acidize Abo formation (ball job)
11. Run completion
12. Swab well in and put on production to the Britt B battery.

RECEIVED
JUN 27 1964
U.S. AIR FORCE