

- E. Cut off dead-man anchors below ground level and remove markers. Fill in cellar and workover pit.
 - F. Remove all equipment, concrete bases, and pipe not in use.
 - G. Clean and restore location to its natural state. Reseed according to BLM requirements.
7. Send a copy of the well service report and final P&A schematic to Kandy Lawson in the Hobbs Office so the proper forms can be filed.

Approved:

Tom C. Eddrell
Engineering Technician

5-22-90
Date

J. H. McEliff
Engineer

5/22/90
Date

J. H. McEliff (for J. E. Porter)
Supervising Production Engineer

7/5/90
Date

W. B. Chabney
Division Engineering Manager

7/6/90
Date

Frank Patton
Production Superintendent

7/9/90
Date