

SEmer Britt No. 61

Pg 2

Pump 2 bbls flush & pressure went to 0 psi. Pump 6 bbls & stopped pumping. Pumped $\frac{1}{4}$ bbl & pressure went to 1000 psi then $\frac{1}{2}$ bbl & pressure went to 1800 psi. Release pressure & unset pke. Set pke, load backside to 500 psi. Pressure up on Hg to 1000 psi. POOH w/pke. Tag cmt at 4155' & dull out. Circulate clean. POOH. Circulate sand off RBP & POOH. Set Hg anchor w/12 pts tension at 5524' & run producing equipment. Work completed on 9/12/87. For further information contact Jay Vashlee at 393-4141.