

NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

MISCELLANEOUS NOTICES

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature of Notice by Checking Below

NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO TEMPORARILY ABANDON WELL		NOTICE OF INTENTION TO DRILL DEEPER	
NOTICE OF INTENTION TO PLUG WELL		NOTICE OF INTENTION TO PLUG BACK		NOTICE OF INTENTION TO SET LINER	
NOTICE OF INTENTION TO SQUEEZE		NOTICE OF INTENTION TO ACIDIZE		NOTICE OF INTENTION TO SHOOT (Nitro)	
NOTICE OF INTENTION TO GUN PERFORATE	<input checked="" type="checkbox"/>	NOTICE OF INTENTION (OTHER)		NOTICE OF INTENTION (OTHER)	<input checked="" type="checkbox"/>

OIL CONSERVATION COMMISSION
SANTA FE, NEW MEXICO

Hobbs, New Mexico

February 22, 1957

Gentlemen:

Following is a Notice of Intention to do certain work as described below at the _____ State of _____

_____ Well No. _____ in _____ (Unit)
_____ Company of Operators
SV (40-acre Subdivision) 1/4 of Sec. 16, T. 22N, R. 37E, NMPM, Monument Pool
_____ County.

FULL DETAILS OF PROPOSED PLAN OF WORK (FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS)

We propose to do the following:

1. Pull tubing. Tag bottom and tally out.
2. Run tubing w/6-1/4" bit.
3. Drill out from 3700' to 3785'. Pull tubing.
4. Perforate w/Western F.I. Gun @ 3774' (Halliburton GR/K log depth).
5. Run tubing w/Lyness Hydraulic Packers. Set packers @ approximately 3760' & 3780'.
6. Swab test. If no water recovered then proceed w/step 7.*
7. Treat down tubing w/5000 gals. gelled crude w/1#/gal. sand. Fluid loss to be about 5 cc. Overflushed w/50 BO. Use 2 Fracmaster 600 pump trucks.
8. Swab back load and test.

*NOTE: If water recovered plug back to 3750' w/pea gravel and from 3750' to 3740' w/hydronite. Perforate w/F.I. Gun @ 3721' and 3733'. Set packers @ 3718' and 3736' and proceed w/step 7.

Approved _____, 19____
Except as follows:

Approved _____
OIL CONSERVATION COMMISSION

By _____
Title _____

By _____
Position _____
Send Communications regarding Well to _____

Name _____
Address _____