

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fed <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
TEXACO Inc.		Eunice Monument Unit
3. Address of Operator		9. Well No.
P. O. Box 728, Hobbs, New Mexico 88240		23
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>J</u> , <u>1980</u> FEET FROM THE <u>East</u> LINE AND <u>1980</u> FEET FROM		Eunice Monument
THE <u>South</u> LINE, SECTION <u>19</u> TOWNSHIP <u>20-S</u> RANGE <u>37-E</u> NMPM.		Grayburg - San Andres
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3533' (DF)		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig Up. Install BOP.
2. Spot 15 sx cement plug from 3724' - 3624'.
3. Cut 5 1/2" casing @ approx. 2700' and pull same.
4. Spot 25 Sx cement plug from 2750' - 2650'.
5. Spot 30 Sx cement plug from 2517' - 2417'.
6. Cut 8 5/8" casing @ approx. 1250' and pull same.
7. Spot 45 Sx cement plug from 1300' - 1200'.
8. Spot 65 Sx cement plug from 326' - 226'.
9. Spot 75 Sx cement plug from 100' - Surface.
10. Install Dry Hole marker and clean location.
11. Plug and abandon well.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Asst Dist Mgr DATE 5-2-83

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE _____

MAY 4 1983

CONDITIONS OF APPROVAL, IF ANY: